

1. COOL DISK Features

COOL DISK is a storage device for desktop and notebook computers. It is using USB port for data transfer; with high storage capacity, removable and slim size, plus SECURE features. Plug-N-Play compatible with Win 98/98SE; Win ME; Win 2000 and Win XP.

- | USB Interface and compliant to USB Specification 1.1
- | Security Password Protection
- | No external power-supply required
- | USB Port Plug-N-Play
- | Easy to use and install
- | Compact and light
- | Support Win 98/98SE; Win ME; Win 2000 and Win XP
- | With Write-Protect Switch
- | LED indication – Power On and Processing

2. System Requirement

| **Hardware Requirements:**

IBM PC or Compatible, PC or Notebook Computer with Universal Serial Bus port
(USB version 1.0 / 1.1)

| **Operating System Requirements:**

Windows 98, Windows 98SE, Windows ME, Windows 2000, Windows XP

Driver Installation

I Installation Procedure for Win 98 / 98SE

~ Do **NOT** plug in the **COOL DISK**.

~ Insert floppy driver disk and run “\Win98\Setup.exe”. (Letter “X” refers to the floppy drive location.)

~ Click “INSTALL”.

~ Reboot the system. After reboot, plug in **COOL DISK** into the computer USB port and Windows will install the driver automatically.

~ Afterwards, in “MY COMPUTER” you will find a new icon “REMOVABLE DISK”. This is the location of **COOL DISK**.

~ Now, you are able to access all features that provided by **COOL DISK**.

** Please also read “UTILITIES” in this installation quick reference.

** To “Uninstall” **COOL DISK**, run “Setup.exe” again and click “UNINSTALL”.

I Installation Procedure for Win ME / Win 2000 / Win XP

There is **COOL DISK** driver support in Win ME / Win 2000 / Win XP. After you plug in **COOL DISK** Windows will automatically install the driver. Just follow the simple installation procedure, and finally, in “MY COMPUTER” you will find a new icon “REMOVABLE DISK”.

~ Now, you are able to access all features that provided by **COOL DISK**.

** Please also read “UTILITIES” in this installation quick reference.

** To “Uninstall” **COOL DISK**, plug off from the USB port.

Utilities

In the driver disk, there are some utilities for **COOL DISK**.

a. mFormat.exe

Available Options:

- ~ Quick / Full Format
- ~ Enable Password Secure Protection feature
- ~ Make Disk Bootable

“mFormat.exe” is used for formatting the **COOL DISK** in “QUICK” or “FULL” style. Also, it allows you to enable or disable the SECURE Protection and BOOTABLE features.

To format the **COOL DISK**, choose “QUICK” or “FULL” and click “Start”. It is recommended to use “QUICK” format for **COOL DISK**. It is good for longer product life time.

** **COOL DISK** has been already formatted for first time use.

If “Password Feature” is enabled, after formatting, the default password is set to be “**1111**”. You are able to modify the password in “Passid.exe”.

If “Make Bootable Disk” is selected, **COOL DISK** will copy some system files for USB booting after formatting. This USB booting function is required mainboard BIOS support. Not all mainboard BIOS has this support. Please check your mainboard supplier for details.

b. Passid.exe

To access the password feature for **COOL DISK**, run “Passid.exe” and provide the correct password. You are also able to modify the password here. This utility has been already bundled in the **COOL DISK** for your daily operation.

When password feature is enabled, after plug off **COOL DISK** from the computer, it would be self locked. When plug-in again, it is requested to enter the password to access.

To disable the password feature, run “mFormat.exe” and disable this feature. Please note that when you click “Start”, the **COOL DISK** is formatted and all data will be lost.

c. UDRReset.exe

If password is forgotten, run this utility to clear everything – including data. You have to run “mFormat.exe” to format the **COOL DISK** again.

** For more product information, please visit our web site : www.z-cyber.net. **